

## Installation instructions for BPE1, BPE2 and BPE3

It is highly recommended that you use a thread lock compound such as Loctite brand on all threads to keep them from vibrating loose.

Please read these instructions entirely before starting.

If you are missing anything please email [RefinedCycle@gmail.com](mailto:RefinedCycle@gmail.com).



Remove your stock rubber pad by removing the 2 screws in the bottom of it.



Install the foot pad (either the stock rubber pad or the metal pad, depending on the model you chose) with the short screws and hardware provided.



The Extension can be installed above or below the original brake pedal using the supplied cover pad, spacers and hardware, depending on desired height and floorboard configuration. You can also opt to not use the spacers on top if it works better for your desired height.